



How to measure your Vertical blind **– recess size (wall to wall measurement)**

1. Always use a metal tape measure.
 2. Take measurements in millimeters.
 3. Specify width first and then drop.
 4. Measure the window recess in 3 places and take the smallest measurement.
 5. Measure the drop, from the top of the window frame down to the windowsill, in 3 places. Use the smallest measurement.
 6. We will make the necessary adjustment for the brackets and so your blinds are just touching the windowsill.
-