



MEASURING, ORDERING, FITTING & CARE

How to measure your Timberlux™ blind

– recess size (wall to wall measurement)

1. Always use a metal tape measure.
2. Take measurements in millimeters.
3. Specify width first and then drop
4. Measure the window recess in 3 places and take the smallest measurement.
5. Measure the drop, from the top of the window frame down to the windowsill, in 3 places. Use the smallest measurement.
6. We will make the necessary adjustment for the brackets and so your blinds are just touching the windowsill.
7. Choose whether you want to face fix, top fix, or side fix your blind.

How to order your Timberlux™ blind

Information you need when ordering your blind:

1. Width – in millimeters
2. Drop – in millimeters
3. Slat size
4. Slat colour
5. Timberlux™ blind style
6. Colour of tape or cord
7. Control option – left/right
8. Method of fitting, i.e. face, top or side fix.

How to fit your Timberlux™ blind

1. Attach End Fix bracket to window recess
2. Open gate on End Fix bracket
3. Slot headrail into the bracket and secure by closing the gate.
4. Larger blinds will have centre supports supplied. These should fitted beside blind ladders.
5. If using Top Swivel bracket, attach to the window face or top fix.
6. Turn swivel 90° and slot headrail into position.
7. Secure by closing swivel bracket

How to care for your Timberlux™ blind

Do not force the tilter mechanism, which in turn will stretch the ladder braid creating a gap at the top of the blind. Due to the nature of wood it is impossible to obtain the same level of closure as when manufacturing aluminium venetians as aluminium can be formed unlike wood.

Keep your Timberlux™ basswood venetians clean by wiping with a dry soft cloth.

Timberlux™ wood blinds are a natural product thus variations in shade, graining as well as warping may occur.